
INSTALLATION INSTRUCTION OF HOSPITAL LATCH FOR PRIVACY FUNCTION

 Insert Latch Bolt into preps hole and fasterned with two #8x3/4" screws.


Privacy Door
-Outside


Privacy Door
-Inside

- 2-1. First, insert 8mm spindle into Latch Bolt square pinion hole.
- 2-2. Second, mounting the inner portion of push/pull chassis onto the Privacy Door inside panel and flush. Make sure the 8mm square spindle and chassis center square hole is joint.




- 3-1. First, placing the outer portion of push/pull chassis onto the both 8mm and 1/4" square spindle and flush to panel.
- 3-2. Second, rotate the 1/4" square spindle to the same orientation as the "indicator pinion" to be install, insert the indicator pinion onto the 1/4" square spindle and fastened with screw.






4. Make sure both inner and outer push/pull chassis's are flush to door panel, and inserts all four 1/4"-20x2-15/32" screws onto 4 bolt through holes from outer chassis and fastened with 4pcs 1/4"-20 hex hex nuts on inner chassis.



- 5-1. Rotate the inner cover thumbturn to the correct orientation before mounting the inner cover onto inner chassis.
- 5-2. Rotate the outer cover indicator pinion to the correct orientation before mounting the outer cover onto outer chassis.



6. Fastened both covers with screws as indicated on either sides of covers, total 4pcs and check the Privacy Indicator is correctly functions.