



NOTE: DO NOT DRILL OR TAP HOLES WHEN OUT SIDE TRIM IS USED. SEE OUTSIDE TRIM TEMPLATE.

- ① TOLERANCE ON ALL FRACTIONAL DIMENDIONS  $\pm 1/64$ "
- ② ● WE RECOMMEND THAT ALL TAPPED HOLES BE DRILLED & TAPPED IN FIELD
- ③ [ SEE STRIKE TEMPLATE FOR TOP AND BOTTOM STRIKES.  
FOR MOUNTOR STRIKE SEE TEMPLATE.
- ④ SEE MASTER SHEET FOR AREAS REQUIRING REINFORCEMENTS
- ⑤ SURFACE OF DOOR WHERE EXIT DEVICE IS TO BE APPLIED MUST BE FLUSH

**Lutér® Fire Command Panic Exit Device**

TEMPLATE: PANIC VERTICAL ROD EXIT DEVICE	日期	10.11.3
	檔名	FC - 9000