



- ① TOLERANCE ON ALL DIMENSIONS $\pm 1/64"$
- ② ● WE RECOMMEND THAT ALL TAPPED HOLES BE DRILLED & TAPPED IN FIELD
- ③ SEE STRIKE TEMPLATE FOR TOP AND BOTTOM STRIKES.
- ④ SEE MASTER SHEET FOR AREAS REQUIRING REINFORCEMENTS
- ⑤ SURFACE OF DOOR WHERE EXIT DEVICE IS TO BE APPLIED MUST BE FLUSH
- ⑥ NO ADDITIONAL DOOR PRERARATION IS REQUIRED FOR MOUNTING THE OUTSIDE TRIM

Lutér® Fire Command Panic Exit Device

TEMPLATE: PANIC VERTICAL ROD EXIT DEVICE	日期	10.11.3
	檔名	FC - 6000